SLIK

6509 クイックシュー

取扱説明書

このたびは、スリック製品をお買い求めいただきまことに
ありがとうございます。ご使用前にこの説明書をよくお読みいただき
正しく、十分に性能を生かしてお使いください。お読みになったあとは
必ず保管し、わからないときには再読してください。

⚠ 注意 このマークは取扱いを誤った場合、人が傷害を負ったり
物的損害の発生が想定される内容です。

⃠ 禁止 このマークは禁止（してはいけないこと）内容です。
説明にしたがい事故のないようお使いください。

English instruction in reverse side

V744

各部名称

付属品

スマートフォンを取り付ける際に、
ネジ部への接触が気になる場合に
ネジ部へ被せてお使いください。

使用可能な スマートフォンサイズ

⚠ 注意

幅　：58mm ～ 90mm
厚さ：12mm 以内

スマートフォンや外装ケースの形状
によっては、上記寸法内でも確実な
取り付けができない場合があります。

カメラの取り付け方



シュー固定レバーを起こしながらクイックシューを
取り外します。
このときシュー固定レバーは、ストッパーにより
起きた状態になっていますので、無理に戻さない
ように注意してください。



ビデオボスは沈下式のため、ビデオカメラ・デジタル
カメラどちらにも使えます。
ビデオカメラの場合は、ボス穴とビデオボスを一致
させて取り付けてください。
カメラの三脚取り付けネジとクイックシューの
カメラネジを合わせてツマミをしっかりと締め付け、
雲台にシューを戻し、シュー固定レバーでしっかり
と締め込みます。



クイックシューは縦向き・横向きどちらでも取り付け
できます。
ビデオカメラの場合は縦向き、デジタルカメラの
場合は横向きで取り付けると安定して撮影できます。

スマートフォンの取り付け方



スマートフォンを取り付けるときは、クイック
シューを図のような向きで取り付けてください。
① クイックシューのスマートフォンホルダー部
　を矢印の方向に起こします。



② カメラ台ストッパーを締め付けます。
③ クランプ部を矢印の方向に起こします。
④ クランプ部を真上に引き上げます。

⚠ 注意



⑤ クランプ部を引き上げながら、スマートフォン
　を取り付けます。
注意：スマートフォンを取り付けるときに、
カメラネジに当たらないように注意してください。

⚠ 注意



使用後は、クランプ部を引き上げながらスマート
フォンを取り外します。
注意：スマートフォンを取り外すときに、
カメラネジに当たらないように注意してください。
また、スマートフォンホルダー部に指をはさまない
ように気を付けてください。



スマートフォンホルダー部を収納するときは、
クランプ部をたたんでからスマートフォンホルダー
部をカチッと鳴るまで押し込んでください。

スマートフォン取り付け時の注意事項

⚠ 注意

・スマートフォンや外装ケースの形状によっては
　使用可能サイズ内でも確実な取り付けができない
　場合があります。
　使用前にご確認ください。
・スマートフォンを取り付けるときに、カメラネジ
　に当たらないように注意してください。
　また、指をはさまないように注意してください。
・スマートフォンホルダー部やクランプ部を過度な
　力で引いたり奥側に倒すと、部品が破損する恐れ
　があります。
　過度な力を掛けないように注意してください。

SLIK

6509 Quick Shoe

Operating Instructions

Thank you very much for choosing SLIK product.
SLIK Corporation has designed to be a sturdy, rugged, dependable product that will provide you with many years of satisfactory use.
Please take a few moments to read this operating instruction carefully before use so that you can take full advantage of many fine features.
Retain this operating instruction in case you might want to refer back to it.

⚠Caution
This caution icon refers to information pertaining to important safety procedures in preventing injuries, or damages which may occur as a result of mishandling this product.

⃠Prohibition
This prohibited icon refers to information pertaining to prohibited contents.
Please refer to instructions closely to avoid accidents.

Components



Applicable Smartphone Size

⚠Caution

Width : 58mm ~ 90mm
Thickness : Within 12mm

Depend on the outward sape of smartphone and its protection case, the smartphone holder may not securely hold it.

Attaching a camera



Remove the quick release shoe turing the lock lever.
In this case, please do not put the lock lever back by force as it has been stood by the stopper.



The retractable video boss enables you to mount either a video camera, or a digital camera.
For the video camera, attach your video camera to the quick release shoe after setting the video boss and the hole of your video camera.
Align the camera mounting screw to the screw hole of the camera and securely tighten the screw into the camera.



The quick shoe can be attached to the pan head in either horizontal or vertical direction.
The quick shoe can be mounted vertically on a video camera and horizontally on a digital camera for a sense of stability.

Attaching a smartphone



When attaching a smatphone to the pan head, place the quick shoe in the direction shown above.
① flip up the smartphone holder in the direction of arrow.



② fix the vertical tilt lock knob.
③ flip up the clamping tab in the direction of arrow.
④ pull the clamping tab upward.

⚠Caution



⑤ insert the smartphone to the smartphone holder while pulling the clamping tab up.
Caution : be careful not hitting the smartphone to the camera screw while its installation.

⚠Caution



Pull up the clamping tab and remove the smartphone from the holder.
Caution : be careful not hitting the smartphone to the camera screw while its remove.
be careful not pinch your finger to the smartphone holder.



To store the smartphone holder in the the quick shoe, retract the clamping tab and push the holder back into the quick shoe body until you hear the clicking sound.

Note when attaching a smaprtphone

⚠Caution

- Depend on the outward sape of smartphone and its protection case, the smartphone holder may not securely hold it.
- be careful not hitting the smartphone to the camera screw while its installation.
- be careful not pinch your finger to the smartphone holder.
- If the smartphone holder or the clamping tab is pulled by excessive force, or push more than it stands, the parts may be damaged.